



DETECTO®

PC-6 DIGITAL PRICE COMPUTING SCALE

Accurate

Weight increment .002 lb

Versatile

Battery operation
Multi-position display

Compact

The smallest price
computing scale available

The market's best value in price computing scales, Detecto's PC-6 with 6 lb capacity is the perfect companion for selling candy, coffee beans, nuts and more. Its space saving size and battery powered operation means true portability for use anywhere! User-friendly keypad and easy-to-read, adjustable display take the guesswork out of price calculations.

DETECTO

Model PC-6

Precise Weight, Accurate Computing, Increased Profits

Good things do come in small packages...

and the PC-6 is small, less than nine inches square, so it doesn't take up valuable counter space in stores, and fits easily in kiosks or vendor carts. In fact, if you lay this piece of paper on your counter, it will take up more space than the PC-6 will! Still the PC-6 provides precise weight to .002 lb and accurate calculations, eliminating many of the errors that occur reading mechanical scales and computing prices on a calculator.

Designed to be versatile, because your store is not like everyone else's

The display attaches to the scale in any of three positions, plus rotates on its column. Battery operation, with internal charger is standard, making the PC-6 usable anywhere. Featuring both pushbutton and keypad tare, and available in pounds or kilograms, 115 or 230 volt power, the PC-6 works the way you do.

Easy-to-use and maintain

Large color-coded keys are incorporated for accurate, simple operation. Adjustable, nonskid feet and internal bubble level ensure steady weighing. The smooth lines of the molded poly enclosure, lift-off stainless steel commodity tray, and sealed membrane keypad make cleaning easy.



Total Price
to \$999.99

Unit Price
to \$99.99

Weight to
6.000 lb

The sharp liquid crystal display provides weight, unit price, and total price together on one line and is mounted four inches above the tray for easy viewing.



Position the display where it works best for you and your customer - the rear, either side of the platform, or remove it from the scale and mount it on the wall.



These scales meet all requirements of Handbook 44, issued by the National Institute of Standards and Technology, and have been issued the Certificate of Conformance number 00-128.



Cardinal Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.



P.O. Box 151, Webb City, MO 64870 USA
Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-5001
Visit our Web site at <http://www.detectoscale.com>

Sold By:



Specifications

Capacity:

PC-6 - 6 lb. x .0002 lb
PC-6KG - 3 kg x .001 kg

Display:

16 character, 3/8" / 9mm high 7-segment LCD

Annunciators:

Gross, Tare, Net, Zero, Low Battery

Keypad:

Solid-state membrane with 17 color-coded keys

Tare:

Pushbutton and keypad

Power:

12 VDC from 115 VAC power adapter or
5 AA Alkaline, Ni-Cad, or Nickel Metal Hydride
(NiMH) batteries (Optional 230 VAC adapter
available)

Dimensions:

Platform - 7 7/8" W x 4 1/2" D
200 mm W x 114 mm D
Base - 8 1/8" W x 8 1/8" D x 3 3/16" H
207 mm W x 206 mm W x 81 mm H
Display - 6 3/4" W x 1 in. D x 3" H
172 mm W x 25 mm D x 76 mm H

Operating

Temperature: +14 to +104 °F / -10 to +40 °C

Weight:

3 lb / 1.4 kg